GPX MOBILE

QUICK START GUIDE

GPX MOBILE DEVICE

1 PIN Code: 9696

2 Open GPX Stream app

3 Select Camera

4 Lock Screen

GPX DASH

5 Login with email & password

6 Tap on your device

7 Tap Start!

PRO TIPS

Forgot to lock your screen? You can do it from GPX Dash!
Locking your screen can double the battery life

Adjust the streaming quality from GPX Dash to suit
network conditions using the Low, Medium, High buttons